



NetWyl Informatik
IT-Security Experts

Cisco Access Point Boot Parameter setzen

Version 1.0

Dokument Name: Cisco Access Point_Boot Parameter setzen

Dokumentenkontrolle

| Version | Datum | Änderungsnotiz | Betroffene Seiten | Status | Author |
|---------|------------|----------------|----------------------|--------|--------|
| 1.0 | 10.07.2024 | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

Copyright 2024 NetWyl Informatik

NetWyl Informatik GmbH
Täschmattstrasse 19
6015 Luzern
info@netwyl-informatik.ch
Phone: +41 41 520 73 90

Password:

AGV_AP_5>ena

Password:

AGV_AP_5#

AGV_AP_5#

AGV_AP_5#

AGV_AP_5#dir

Directory of flash:/

```
 2 -rwx   1820 May 25 2022 11:50:26 +00:00 config.txt
 3 -rwx  525184 May 25 2022 11:52:00 +00:00 r0.rcore
 4 drwx   320 Jan 1 1970 00:06:08 +00:00 c1240-k9w7-mx.124-10b.JDA3
154 -rwx   1048 May 25 2022 11:50:26 +00:00 private-multiple-fs
155 -rwx  4737904 May 25 2022 11:48:45 +00:00 c1240-k9w7-mx.124-25d.JA1
157 -rwx     5 May 25 2022 11:50:26 +00:00 private-config
158 -rwx   289 Mar 1 2002 00:00:25 +00:00 env_vars
```

15740928 bytes total (4974080 bytes free)

AGV_AP_5#

AGV_AP_5#

AGV_AP_5#

AGV_AP_5#cd c1240-k9w7-mx.124-10b.JDA3

AGV_AP_5#dir

Directory of flash:/c1240-k9w7-mx.124-10b.JDA3/

```
 5 drwx    64 Jan 1 1970 00:00:49 +00:00 html
150 -rwx  4552901 Jan 1 1970 00:06:00 +00:00 c1240-k9w7-mx.124-10b.JDA3
151 -rwx  131328 Jan 1 1970 00:06:04 +00:00 7101.img
152 -rwx  131328 Jan 1 1970 00:06:08 +00:00 6701.img
153 -rwx   283 Jan 1 1970 00:06:08 +00:00 info
```

15740928 bytes total (4974080 bytes free)

AGV_AP_5#show boot

BOOT path-list: flash:/c1240-k9w7-mx.124-25d.JA1

Config file: flash:/config.txt

Private Config file: flash:/private-config

Enable Break: no

Manual Boot: no

Enable IOS Break: no

HELPER path-list:

NVRAM/Config file

buffer size: 32768

Mode Button: on

Radio Core TFTP:

AGV_AP_5#conf t

Enter configuration commands, one per line. End with CNTL/Z.

AGV_AP_5(config)#boot flash:/c1240-k9w7-mx.124-10b.JDA3/c1240-k9w7-mx.124-10b.JDA3

% Invalid input detected at '^' marker.

AGV_AP_5(config)#boot system flash:/c1240-k9w7-mx.124-10b.JDA3/c1240-k9w7-mx.124-10b.JDA3

```
AGV_AP_5(config)#
AGV_AP_5(config)#
AGV_AP_5(config)#
AGV_AP_5(config)#end
AGV_AP_5#sho boot
BOOT path-list:  flash:/c1240-k9w7-mx.124-10b.JDA3/c1240-k9w7-mx.124-10b.JDA3
Config file:     flash:/config.txt
Private Config file: flash:/private-config
Enable Break:    no
Manual Boot:     no
Enable IOS Break: no
HELPER path-list:
NVRAM/Config file
  buffer size: 32768
  Mode Button:  on
Radio Core TFTP:
AGV_AP_5#wri
Building configuration...
[OK]
AGV_AP_5#
```

```
AGV_AP_23#show boot
BOOT path-list:  flash:/c1240-k9w7-mx.124-25d.JA1/c1240-k9w7-mx.124-25d.JA1
Config file:     flash:/config.txt
Private Config file: flash:/private-config
Enable Break:    no
Manual Boot:     no
Enable IOS Break: no
HELPER path-list:
NVRAM/Config file
  buffer size: 32768
  Mode Button:  on
Radio Core TFTP:
AGV_AP_23#
AGV_AP_23#
AGV_AP_23#
```

```
conf t
boot system flash:/c1240-k9w7-mx.124-25d.JA1
end
wir mem
!
show boot
!
reload
```